

June 23, 2022



**PRELIMINARY BUILD SPECIFICATION**

Quote # QUO0000006844

Production #

Document Rev. # 3

Status: Ready for Submission

**Prepared For:**

Tom Gallo  
City of Hollywood  
2741 STIRLING ROAD  
HOLLYWOOD,  
FL  
33312  
Phone:

**Presented By:**

Scott Newcomer  
ETR,LLC  
700 South French Ave  
Sanford, FL  
32771  
Phone: 407-339-6737

Option	QTY	Description
<b>CHASSIS</b>		
1000-0002	1	<b>AMBULANCE SPECIFICATIONS</b>
SR00160851	1	PREVIOUS UNIT - 19423-24  Note - Not an exact duplicate.
1000-0885	1	<b>CHASSIS, 2023 FREIGHTLINER M2,174, DEALER SUPP</b> The chassis required to complete the ambulance conversion shall be supplied by the customer or selling dealer.
1000-0085	1	<b>CHASSIS ORDERED WITH ALUM WHEELS, MD</b> The chassis will include aluminum OEM wheels.
1000-0065	1	<b>WALK THROUGH FOR FREIGHTLINER</b> Type 1 Freightliner chassis to be modified to provide walk through access to the patient area.
SR00149795	1	2" SHIFT WALKTHROUGH  SHIFT WALKTHROUGH 2" TOWARD CURBSIDE TO ACCOMMODATE THE 20" DEEP LINEN CABINET
SR00150479	1	Freightliner hub and lug nut covers for 8 lugs  Install chrome finish hub and lug nut covers for Freightliner 8 lug wheels.
1000-0073	1	<b>TIRE SIZE, 19.5", MEDIUM DUTY:</b> This chassis is specified to have 19.5" tires.
1000-0080	1	<b>CHASSIS IS EQUIPPED WITH HORIZONTAL EXHAUST</b> The chassis specified above is to include a horizontal exhaust.

Spec Writer: **Levi C**

Spec Designer:

**CITY OF HOLLYWOOD**

Option	QTY	Description
1000-0083	1	<b>STANDARD CAB HEIGHT</b> The specified chassis will have the standard cab height.
1000-0259	1	<b>MUD FLAPS FRONT, FREIGHTLINER</b> Install mud flaps behind each front tire.
1000-0348	1	<b>MUD FLAPS, REAR, LARGE W/O LOGO</b> Install individual rear mud flaps behind each set of rear wheels. Mud flaps to be plain black without logo.
1000-0281	1	<b>ENERGY ABSORBING FLIP-UP STEP/EMBOSSSED, FREIGHTLINER</b> Install an energy absorbing rear step/bumper assembly with flip-up center section. Material to be embossed diamondplate.
<b>BODY</b>		
SR00149745	1	<b>REINFORCE THE WALL AT HEAD OF BENCH FOR THE MAX COOL UNIT</b>
SR00149848	1	PLYMOVENT MOD.: Horton to modify exhaust throughout the drop skirt, the body to match previous, see drawings. Horton to supply all modification parts necessary to reroute. Horton to install a stainless steel plate to surround the opening. The customer would like this to be polished type ILO stainless steel.  (1) PLYMOVENT 5"-4" REDUCER PV-90365-1011 (HPN - 10013250) (1) PLYMOVENT 5" TAILPIPE ADAPTER PV-90360-1 (HPN10013251) (1) 4" U-STYLE ZINC CLAMP HD-18-400Z (2) 4" FLEX EXHAUST PIPE (409SS) 2L50400X10 (HPN 10002723) (10) STAINLESS STEEL TIE STRAPS DEi010202 (1) TITANIUM EXHAUST WRAP DE 1010131 (1) PLYMOVENT TAILPIPE EXHAUST TIP, 4" OD - 8975-1011/ADAP-003 (HPN 10002792)
2000-0173	1	<b>AMBULANCE BODY</b> Conversion model is to be a 623 using a Freightliner chassis. Body length is 173".
SR00149767	1	<b>CUSTOM CRASH BARRIER COMPARTMENT CONFIGURATION -</b>  The side access door is to be relocated at the forward most area on the curbside of the body. The space between the door and the head of the bench is to be occupied by an inside/outside access compartment. Compartment to include standard LED strip lighting.  Curbside wheelhouse will extend to the crash barrier and rear compartment. Custom crash barrier compartments with two exterior doors. Locate between the side entry door and the wheel house. See drawings for dimensions. Include aisle side I/O opening sized as wide as possible and close to floor as possible.  Lower separate compartment vented battery compartment door to be 28W x 17.54H (OD) with single hinged door. Each door is to have (1) Nader pin ILOS to duplicate previous vehicles. Install OEM batteries with slide-out battery tray with heavy duty slides. Install a total of (2) diamond plate adjustable shelves. Note - Battery tray spec'd elsewhere.

Spec Writer: **Levi C**

Spec Designer:

**CITY OF HOLLYWOOD**

Option	QTY	Description
		Reference 19423-24
<b>SR00149816</b>	<b>1</b>	<b>HEADROOM - 76":</b> REAR DOOR HEIGHT TO BE INCREASED 2" FROM STD. - SAME AS 17616-17618
<b>2000-0625</b>	<b>1</b>	<b>ALUM. DIAMONDPLATE AT SIDE STEPWELL</b> Fabricate the stepping surface inside the side access door using polished aluminum diamond treadplate.
<b>2000-0245</b>	<b>1</b>	<b>DOUBLE STEP CURBSIDE ENTRY, 6" DROP SKIRT</b> Fabricate curbside of body with 6" drop skirt. To include two step side entry.
<b>2000-0246</b>	<b>1</b>	<b>STREETSIDE 6" DROP SKIRT</b> <p>Fabricate streetside of body with 6" drop skirt. </p>
<b>2000-0250</b>	<b>1</b>	<b>SOUND PROOFING/ACOUSTIC ENHANCEMENT PACKAGE</b> Install standard sound control package.
<b>2000-0260</b>	<b>1</b>	<b>WINDOW, SLIDING FOR SIDE ENTRY DOOR</b> Install a clear sliding window in the side access door.
<b>SR00149760</b>	<b>1</b>	REAR ENTRY WINDOWS  THE REAR ENTRY DOOR WINDOWS IS TO BE SLIDING.
<b>2000-0265</b>	<b>2</b>	<b>EMERGENCY RELEASE, REAR DOORS</b> Install standard emergency release knobs on top and bottom of the rear module entrance doors.
<b>2000-0704</b>	<b>1</b>	<b>EMERGENCY RELEASE, SIDE ACCESS DOOR</b> Install emergency release knobs on top and bottom of the side module entrance door.
<b>2000-0010</b>	<b>1</b>	<b>DOOR HANDLES</b> Install Tri-Mark free floating style door handles with pre-stretched stainless steel cables. Include three piece interior door panels on all access doors.
<b>2000-0814</b>	<b>1</b>	<b>VI-TECH MOUNTING, FREIGHTLINER</b> Install standard Vi-Tech body mounts.
<b>2000-0270</b>	<b>1</b>	<b>MIRROR STAINLESS STEEL SPLASH SHIELDS</b> Install #8 mirror stainless splash shields on the lower front face of the body just behind the cab access doors. These splash shields are to be the same height as the diamond plate front corner guards.
<b>2000-0509</b>	<b>1</b>	<b>FENDERS, RUBBER</b> Install rubber extruded fenders around the rear wheel well openings.
<b>2000-0586</b>	<b>1</b>	<b>C CHANNEL RUB RAILS</b> Install 'C' channel style lower body rub rails.
<b>2000-0652</b>	<b>1</b>	<b>STANDARD CORNER GUARDS</b> Install standard height polished diamondplate corner guards.

Spec Writer: **Levi C**

Spec Designer:

**CITY OF HOLLYWOOD**

Option	QTY	Description
2000-0281	1	<b>REAR DOOR HOLD OPENS, GRABBER</b> Install chrome Cast Products "Grabber" style rear door hold opens. (NOTE: HOLDOPENS MUST BE RELOCATED IF TELESCOPIC LIGHTS ARE ORDERED)
2000-0583	1	<b>ENTRY DOOR THRESHOLDS, LINE-X</b> Apply black Line-X to the side and rear entry door thresholds. Delete the standard anti-slip tape.
2000-0584	1	<b>REAR RISER ADP</b> The rear riser is to be fabricated out of polished aluminum diamondplate.
2000-0686	1	<b>LICENSE PLATE, CENTER OF REAR RISER, WITH REVERSE LIGHTS</b> Install a recessed rear license plate bracket with integral reverse lights centered in the rear riser. Include an LED license plate light.
SR00149853	1	<b>FUEL TANK COVERS: INSTALL STAR PUNCHED TANK COVERS. REFERENCE 19423-24</b>
2000-0598	20	<b>DOOR REFLECTORS</b> All patient compartment entry doors to include standard red reflectors.
<b>COMPARTMENTATION</b>		
2900-1571	1	<b>STREETSIDE FORWARD COMPARTMENT</b> The height of the streetside front compartment is to be the full available height of the body. See drawings for compartment dimensions. Compartment is to include standard LED strip lighting and a single hinged door.
2000-0401	1	<b>SS FORWARD COMPT. FLAT ALUMINUM</b> The streetside forward compartment is to be fabricated from flat aluminum.
2900-0004	2	<b>ADJUSTABLE SHELF STREETSIDE FRONT BETWEEN DIVIDER AND RIGHT COMPARTMENT WALL. - SHELF TRACK TO START 40" FROM FLOOR OF COMPT. AND RUN</b> Install diamond plate adjustable shelving in the streetside forward compartment. Locate as noted.
2900-0219	1	<b>FIXED VERTICAL DIVIDER, STREETSIDE FRONT 10" FROM RIGHT COMPARTMENT WALL</b> Install a 16" deep fixed vertical divider in the streetside forward compartment. Locate as noted above.
2900-0106	1	<b>ROK BACKBOARD STRAP STREETSIDE FRONT BETWEEN DIVIDER AND LEFT COMPARTMENT WALL, MID-HEIGHT FOR</b> Install a Rok buckle style backboard strap in the designated compartment.
2000-0225	1	<b>SWEEP OUT COMPARTMENT FLOOR, SS FRONT</b> Streetside forward compartment floor is to be sweep-out style.
2900-1574	1	<b>STREETSIDE INTERMEDIATE COMPARTMENT</b> The height of the streetside intermediate compartment is to be the full available height to the bottom of the interior countertop. See drawings for compartment dimensions. Compartment is to include standard LED strip lighting and double hinged doors.
2000-0402	1	<b>SS INTRMDT COMPT. DIAMONDPLATE</b> The streetside intermediate compartment is to be fabricated from diamondplate.
SR00149808	1	STREETSIDE INTERMEDIATE COMPARTMENT

Spec Writer: **Levi C**

Spec Designer:

**CITY OF HOLLYWOOD**

Option	QTY	Description
		SUPPLY A ZICO SC-50-H-6-SF SCBA BRACKET CADDY. HORTON TO FABRICATE AN ANGLED BRACKET/PLATE AND INSTALL ON LEFT REAR CORNER FOR SCBA STORAGE.
2900-0144	1	<b>ADJUSTABLE SHELF STREETSIDE INTERMEDIATE BETWEEN PD BOX AND DIVIDER, REDUCED 1 1/4 FOR FUTURE SET OF PRO BAR &amp; FLAT HEAD AXE ON DOOR</b> Install diamond plate adjustable shelving in the streetside intermediate compartment. Locate as noted.
2900-0242	1	<b>ELECTRICAL DIVIDER, STREETSIDE INTERMEDIATE 10" FROM RIGHT COMPARTMENT WALL</b> Install a fixed vertical divider in the streetside intermediate compartment 12" from the wall. Locate to isolate the onboard electrical equipment from the remainder of the storage within the compartment.
1000-0308	1	<b>RIGHT SIDE MOUNTED ELECTRICAL EQUIPMENT</b> Install the onboard electrical components on the right side of the streetside intermediate compartment.
2900-0252	1	<b>EXPANDED METAL CAGE, STREETSIDE INTERMEDIATE</b> Install an expanded metal cage around the onboard electrical equipment per location noted above. Include access ports to equipment with grip lock around the edges of the openings.
SR00149791	1	DIAMOND PLATE COMPT. OVER THE SS WHEELHOUSE:. THE COMPT. IS TO BE MAX WIDTH - APPROX. 20H. TOP OF THE COMPT. IS TO LINE UP W/ THE STREETSIDE INTERMEDIATE COMPT. AND THE STREETSIDE REAR COMPT. COMPT. IS TO HAVE DOUBLE HINGED DOORS AND (1) ADJUSTABLE SHELF
8000-0145	1	<b>SS WHEELWELL COMPARTMENT, DELETE</b> Vehicle is not equipped with a streetside wheelwell compartment.
2900-1580	1	<b>STREETSIDE REAR COMPARTMENT</b> The height of the streetside rear compartment is to be half of the available height of the body. See drawings for compartment dimensions. Compartment is to include standard LED strip lighting and double hinged doors.
2000-0404	1	<b>SS REAR COMPT. DIAMONDPLATE</b> The streetside rear compartment is to be fabricated from diamondplate.
SR00149794	1	STREETSIDE REAR COMPARTMENT  SUPPLY A ZICO SC-50-H-6-SF SCBA BRACKET CADDY. HORTON TO FABRICATE AN ANGLED BRACKET/PLATE AND INSTALL ON LEFT REAR CORNER FOR SCBA STORAGE.
2900-0145	1	<b>ADJUSTABLE SHELF STREETSIDE REAR LOCATE BELOW THE SCBA BRACKET SET UP</b> Install diamond plate adjustable shelving in the streetside rear compartment. Locate as noted.
2900-1585	1	<b>CURBSIDE REAR COMPARTMENT</b> The height of the curbside rear compartment is to be 1/2 available height of the body. See drawings for compartment dimensions. Compartment is to include standard LED strip

Spec Writer: **Levi C**

Spec Designer:

**CITY OF HOLLYWOOD**

Option	QTY	Description
		lighting and a single hinged door.
<b>2000-0408</b>	<b>1</b>	<b>CS REAR COMPT. DIAMONDPLATE</b> The curbside rear compartment is to be fabricated from diamondplate.
<b>SR00149836</b>	<b>1</b>	<b>CURBSIDE REAR NOTE: COMPT. TO BE 2 DOORS ILO (1)</b>
<b>SR00149829</b>	<b>1</b>	CURBSIDE REAR COMPARTMENT WIDTH AND HEIGHT MODIFICATION  REDUCE THE CURBSIDE REAR COMPARTMENT HEIGHT TO BOTTOM OF BENCH CUSHION. INCREASE THE WIDTH AS MUCH AS POSSIBLE.
<b>SR00149792</b>	<b>1</b>	CURBSIDE REAR COMPARTMENT  SUPPLY A ZICO SC-50-H-6-SF SCBA BRACKET CADDY. HORTON TO FABRICATE AN ANGLED BRACKET/PLATE AND INSTALL ON LEFT REAR CORNER FOR SCBA STORAGE.
<b>8000-0090</b>	<b>1</b>	<b>CS INTRMDT COMPT, DELETE</b> Vehicle is not equipped with a curbside intermediate compartment.
<b>3000-0126</b>	<b>1</b>	<b>PULL OUT TRAY FOR 3-BATTERY SYSTEM</b> Install a custom battery tray for (3) batteries in the battery storage location.
<b>2900-1200</b>	<b>1</b>	<b>MATEFLEX, BLACK</b> Black Mateflex is to be installed on the floor and shelving of all exterior compartments. To include tapered edge trim pieces where applicable.
<b>2900-0113</b>	<b>1</b>	<b>RUBBER WALLS IN BB COMPT, GRAY</b> The interior of the backboard compartment is to be covered with gray rubber matting to protect equipment stored in this area.
<b>2900-0114</b>	<b>1</b>	<b>GRIP LOCK, FACE OF EXTERIOR SHELVES AND DIVIDERS</b> Install grip lock trim on the edges of the compartment shelves and any vertical dividers.
<b>PAINT AND GRAPHICS</b>		
<b>SR00149786</b>	<b>1</b>	<b>BUMPER: THE CHASSIS IS TO ARRIVE WITH THE FRONT BUMPER PAINTED GRAY. HORTON IS TO NOT PAINT THE BUMPER.</b>
<b>SR00150456</b>	<b>1</b>	<b>C CHANNEL RUB RAILS - SCOTCHLITE STRIPING : INSTALL DOT RED/WHITE SCOTCHLITE STRIPING INSIDE THE C CHANNEL RUB RAILS .</b>
<b>SR00149747</b>	<b>1</b>	CHASSIS PAINT - PIERCE #90 CROSSED TO FLNA3042 / FLNA94109  Paint Freightliner chassis special color as noted above. UPPER PORTION OF CHASSIS GRAY AND LOWER PORTION RED. HOOD, UPPER PORTION OF CHASSIS AND CHASSIS ROOF TO BE GRAY. BOTTOM OF CHASSIS TO BE RED. SEE REFERENCE PHOTOS IN 19423 PHOTOS FOLDER AND MATCH.
<b>5000-0189</b>	<b>1</b>	<b>MODULE PAINT pierce 90 - gray 94109</b>

Spec Writer: **Levi C**

Spec Designer:

**CITY OF HOLLYWOOD**

Option	QTY	Description
		The module body is to be painted a special paint color and paint code as noted above.
SR00149835	1	<p>MODULE PAINT:</p> <p>BODY TO BE PAINTED GRAY OVER RED. PAINT THE BODY RED FROM 1" BELOW THE EXHAUST VENTS DOWN TO BOTTOM OF BODY. PAINT THE BODY GRAY FROM 1" UNDER EXHAUST VENTS UP OVER THE EXTRUSIONS. THE AC CONDENSER ON THE FRONT OF BODY TO BE GRAY AS WELL. PAINT THE FLAT PORTION OF THE BODY ROOF WHITE.</p>
5000-0014	1	<p><b>PAINT PANEL: SAMPLE pierce 90 - gray 94109</b></p> <p>A painted test panel shall be prepared with the paint color and number noted above,</p>
5000-0036	1	<p><b>PAINT PANEL: CHASSIS PIERCE #90 CROSSED TO FLNA3042 / FLNA94109</b></p> <p>A painted test panel shall be prepared with the paint color and number noted above, This panel is specific to the chassis repaint selected.</p>
5000-0044	1	<p><b>PAINT CONDENSER, FRONT FACE, TO MATCH BODY:</b></p> <p>Paint the specified auxiliary face-mounted condenser to match the body color. Standard color is white.</p>
SR00149748	1	<p>DIAMOND GRADE CHEVRON:</p> <p>SUPPLY &amp; INSTALL (3) PIECES OF DIAMOND GRADE MATERIAL INSTALLED HORIZONTALLY ON THE INSIDE OF REAR DOORS.</p>
SR00149827	1	<p>(3) DROP IN NUMBER PLATES</p> <p>(3) ALUMINUM DROP IN NUMBER PLATES WITH FRAMES - TO MATCH THE RED ON THE BODY 12"w X 9" h PAINT PLATES AND BRACKETS TO MATCH THE BODY</p>
SR00149798	1	<b>OVERALL HEIGHT STICKER ON THE FRONT WINDOW - RED</b>
5000-0268	1	<p><b>Federal Lettering Package Ship loose</b></p> <p>Ship loose the Federal lettering package, consisting of, (2) 4" SOL (2) 12" SOL (2) 18" SOL (1) 36" SOL (1) 4" Mirror image ambulance (3) 6" Ambulance SEE DRAWINGS</p>
5000-0190	3	<p><b>ACCESS DOORS RED SCOTCHLITE STRIP</b></p> <p>Install 2" x 12" strips of red Scotchlite at the top of each entry door placed horizontally.</p>
<b>INTERIOR FEATURES</b>		
SR00149854	1	<p>SEAT BELT BRACKETS</p> <p>ADD SEAT BELT BRACKETS TO THE SEAT BELTS ON THE RISER TO HOLD THE SEAT BELT</p>

Spec Writer: **Levi C**

Spec Designer:

**CITY OF HOLLYWOOD**

Option	QTY	Description
		FROM FALLING.
2000-0288	1	<b>ACRYLIC COLOR: LIGHT TINT</b> All acrylic doors to be light tint.
2000-0293	3	<b>STAINLESS STEEL COUNTER TOPS main wall cabinet area, crash barrier and foot of bench</b> Fab and install Stainless pan formed countertops in the patient area.
SR00149849	1	<b>STAINLESS STEEL COUNTER TOP - FOOT OF BENCH NOTES</b>  NO LIPS ON THE REAR PORTION OF THE SQUAD BENCH. TOP OF THE STAINLESS COUNTER IS TO SIT .50" LOWER THAN TOP OF THE BENCH CUSHION.
2000-0299	1	<b>STAINLESS STEEL-INHALATION AREA WALLS:</b> The rear and side walls bordering the inhalation area are to be covered with brushed stainless steel.
2000-0301	1	<b>STAINLESS STEEL-INHALATION PANEL:</b> The inhalation panel is to be fabricated from brushed stainless steel. All edges are to be filed.
SR00149765	1	INHALATION PANEL  NOTE: INHALATION PANEL IS ANGLED ILO STRAIGHT
2000-0455	1	<b>LONCOIN FLECKSTONE MOONSTONE #157TS</b> The patient area floor is to be covered in Loncoin Fleckstone Moonstone #157TS.
2000-0324	1	<b>STAINLESS STEEL RISERS</b> Install stainless steel on the interior risers. If a cabinet riser accent stripe is ordered the stainless steel will stop at the bottom edge of the stripe.
2000-0333	1	<b>LAMINATE COVERED LOWER DOOR PANELS</b> Finish lower section of interior patient compartment door panel with laminate as described in the Interior Color section.
2000-0441	1	<b>WILSONART FASHION GRAY #D381, WALLS</b> The interior walls are to be made of reinforced structural composite board covered with Wilsonart Fashion Gray #D381 laminate. This does not apply to areas surrounding the inhalation/CPR seat area.
2000-0667	1	<b>FASHION GREY CABINET COLOR</b> All interior cabinetry is to be painted Fashion Grey.
2000-0710	1	<b>CABINET PAINT TO BE TEXTURED</b> The specified cabinet paint is to have a textured finish.
2000-0944	1	<b>GREYSTONE VINYL COLOR</b> All seat cushions, backrests and vinyl closeouts are to be covered in Greystone colored material.
2000-0326	1	<b>STANDARD FIXED SEATBASE</b> Install the standard aluminum fixed seat base for the attendant's seat specified.
2000-0331	1	<b>USSC CHILD, BLACK 4-POINT, FLINT GREY</b> Install a Flint Gray USSC high back bucket seat with integral child safety seat and black 4pt

Spec Writer: **Levi C**

Spec Designer:

**CITY OF HOLLYWOOD**



Option	QTY	Description
		seatbelt with safety vest. The seat to be adjustable front to rear and is to be mounted at the head of the cot.
<b>2000-0680</b>	<b>1</b>	<b>4 POINT SEAT BELT CENTER OF BENCH, BLACK</b> Install black 4-pt seatbelt with safety vest at the center position of the squad bench.
<b>2000-0681</b>	<b>1</b>	<b>4 POINT SEAT BELT FOOT OF BENCH, BLACK</b> Install black 4-pt seatbelt with safety vest at the foot position of the squad bench.
<b>2000-0682</b>	<b>1</b>	<b>4 POINT SEAT BELT HEAD OF BENCH, BLACK</b> Install black 4-pt seatbelt with safety vest at the head position of the squad bench.
<b>2000-0605</b>	<b>1</b>	<b>ALUMINUM INTERIOR CABINETS</b> All interior cabinets are to be fabricated from aluminum.
<b>3000-1121</b>	<b>1</b>	<b>TUBULAR AIRBAG, ATTENDANT'S SEAT</b> Install a tubular airbag at the attendant's seat. Unit uses a straight upper inhalation cabinet and does not include a cabinet beneath the main countertop.
<b>3000-1125</b>	<b>1</b>	<b>HEAD CURTAIN AIRBAG, ATTENDANT'S SEAT</b> Install a head curtain air bag for the attendant's seat for use with a standard linen cabinet.
<b>3000-1123</b>	<b>1</b>	<b>ROLL SENSOR</b> Install the roll sensor in the standard location. Unit includes streetside airbags only.
<b>2000-0421</b>	<b>1</b>	<b>CABINET TRIM 90 DEGREE</b> Install smooth 90 degree trim molding on all applicable interior cabinets.
<b>2000-0415</b>	<b>1</b>	<b>GRAB RAIL: 6FT ANTI-MICROBIAL, OVER COT Per Drawing</b> Install a standard style 6' main grab rail with anti-microbial coating. Locate offset toward the main wall over the cot position in the patient area ceiling.
<b>2000-0419</b>	<b>1</b>	<b>PATIENT DOOR GRAB RAILS: ANTI-MICROBIAL</b> Install standard 'V' shaped grab rails with anti-microbial coating. Locate on the interior door panels of all three patient entry doors.
<b>SR00149822</b>	<b>1</b>	<b>FOAM COVERED HANDLES: SUPPLY AND INSTALL (2) 9/01228 FOAM COVERED HANDLES. INSTALL (1) ON THE STEPWELL SIDE OF THE CRASH BARRIER AND (1) ON THE REAR CURBSIDE RISER. INSTALL BOTH TO ASSIST WITH ENTRY</b>
<b>2000-0423</b>	<b>1</b>	<b>CEILING MATERIAL, PLATINUM WHITE COMPOSITE</b> The standard module ceiling material shall be platinum white aluminum composite.
<b>2000-0578</b>	<b>1</b>	<b>FIRE EXTINGUISHERS: 5LB ABC SHIP LOOSE</b> Supply and ship loose a five lb ABC fire extinguisher.
<b>2000-0579</b>	<b>1</b>	<b>FIRE EXTINGUISHERS: 5LB ABC SHIP LOOSE</b> Supply and ship loose a second five lb ABC fire extinguisher.
<b>2000-0488</b>	<b>1</b>	<b>INDUCT 500-12V UV</b> Install an ActivTek Health Solution Systems Induct 500-12V UV system in the HVAC duct. Install on a removeable Stainless Steel plate. The system is to activate anytime the blower is operating. A green indicator light labeled "Air Purification System" is to be installed and programmed to activate when the system is operating.
<b>STREETSIDE CABINETRY</b>		
<b>SR00149830</b>	<b>1</b>	SS CABINETRY NOTE

Spec Writer: **Levi C**

Spec Designer:

**CITY OF HOLLYWOOD**

Option	QTY	Description
		<p>MAKE THE FRONT FLANGE OF THE INHALATION AREA INTERIOR SHELVES 1" TALL ILOS, ALL OTHER FLANGE TO REMAIN STANDARD HEIGHT.</p> <p>CUSTOMER WILL BE SUPPLYING BLUE STORAGE BINS TO PUT IN THIS AREA. SEE PHOTO ON V:DRIVE.</p>
SR00150461	1	<p>CARGO NETS, MAIN SIDE</p> <p>INSTALL CARGO NETS WITH ANCRA CLIPS ON LOWER LINEN AND THE REAR MAIN CABINET PER DRAWINGS.</p>
2000-0337	1	<p><b>LINEN CABINET</b></p> <p>Install a standard storage cabinet behind the attendant seat.</p>
2900-1076	1	<p><b>FIXED SHELF, UPPER LINEN CLOSET</b></p> <p>Fab and install a fixed aluminum shelf in the upper section of the linen cabinet. Shelf is to be painted to match the cabinet color.</p>
2900-1079	1	<p><b>ADJUSTABLE SHELF MIDDLE 1 LINEN CLOSET</b></p> <p>Fab and install an adjustable aluminum shelf in the middle section of the linen cabinet. Shelf is to be painted to match the cabinet color.</p>
2900-1082	1	<p><b>FIXED SHELF, LINEN CLOSET, LOWER SECTION</b></p> <p>Fab and install a fixed aluminum shelf in the lower section of the linen cabinet. Shelf is to be painted to match the cabinet color.</p>
2900-2029	2	<p><b>SOLID LAMINATE-COVERED LINEN CLOSET DOOR</b></p> <p>Install hinged solid doors on the linen cabinet. Cover in laminate to match the interior.</p>
2900-1070	1	<p><b>PIANO HINGE FOR LINEN CLOSET TOP DOOR</b></p> <p>The upper linen cabinet door(s) is/are to use piano style hinge.</p>
2900-1072	1	<p><b>PIANO HINGE FOR LINEN CLOSET MIDDLE DOOR</b></p> <p>The middle linen cabinet door(s) is/are to use piano style hinge.</p>
2900-1183	1	<p><b>LOCKING SOUTHCO LATCH, UPPER LINEN, CHANGE 10</b></p> <p>Install a locking stainless flush mount Southco HD style pull latch on the upper linen cabinet door. <b>Latch to be Change Notice 10 compliant and rated for 25lbs.</b></p>
2900-1184	1	<p><b>SOUTHCO LATCH, MIDDLE LINEN, CHANGE 10</b></p> <p>Install a stainless flush mount Southco pull latch on the middle linen cabinet door. <b>Latch to be Change Notice 10 compliant and rated for 25lbs.</b></p>
SR00149777	1	<p>LINEN CLOSET: INCREASE THE DEPTH OF THE CABINET BY 2" FOR A TOTAL DEPTH OF 20" DEEP.</p> <p>BOTTOM SECTION IS TO BE OPEN STORAGE WITH A PULL OUT TRAY. OPEN STORAGE AREA IS TO BE 18"H (ID) - ABOVE THE TRAY.</p> <p>FABRICATE A FLAT ALUMINUM, D/A FINISHED SLIDE OUT TRAY WITH .75" LIPS ON ALL SIDES. INSTALL WITH BOTTOM MOUNT SLIDES ON THE FLOOR OF THE LINEN CLOSET. INSTALL A GAS SHOCK TO HOLD THE TRAY IN THE OEN AND CLOSED POSITIONS.</p> <p>NOTE - CARGO NET SPEC'D ELSEWHERE.</p>

Spec Writer: **Levi C**

Spec Designer:

**CITY OF HOLLYWOOD**

Option	QTY	Description
2000-0342	1	<b>STREETSIDE WALL WITHOUT CPR SEAT</b> Street side cabinet wall does not include a CPR seat.
2000-2050	1	<b>CUSTOM CABINET, Cabinet 1 Dimensions: 46.50" W x 18.75" H x 18" D (ID) - Location: Upper Rear</b> Main wall cabinet #1 dimensions are to be as noted above. Note that dimensions are I.D.
2000-1360	1	<b>POLYCARBONATE SLIDING, CHANGE 10, CABINET 1</b> Cabinet specified above is to have sliding polycarbonate doors. Doors to include CN-10 compliant catch and angled corner brackets.
2900-0412	1	<b>LIFT UP CABINET FRAMES INTERIOR Cabinet 1</b> Install a flip-up restocking cabinet frame on cabinet noted above. Includes gas shocks and vertical latches. <b>The Design is to be compliant with Change Notice 10.</b>
2900-0061	1	<b>INTERIOR ADJUSTABLE SHELVING Cabinet 1</b> Install painted adjustable shelving in cabinet #1.
2000-2051	1	<b>CUSTOM CABINET, Cabinet 2 Dimensions: 36.75" W x 18.75" H x 18" D (ID) - Location: Rear of Inhalation Cabinet</b> Main wall cabinet #2 dimensions are to be as noted above. Note that dimensions are I.D.
2000-1361	1	<b>POLYCARBONATE SLIDING, CHANGE 10, CABINET 2</b> Cabinet specified above is to have sliding polycarbonate doors. Doors to include CN-10 compliant catch.
2900-0413	1	<b>LIFT UP CABINET FRAMES INTERIOR Cabinet 2</b> Install a flip-up restocking cabinet frame on cabinet noted above. Includes gas shocks and vertical latches. <b>The Design is to be compliant with Change Notice 10.</b>
2900-0172	1	<b>INTERIOR ADJUSTABLE SHELVING, Cabinet 2</b> Install painted adjustable shelving in cabinet #2.
SR00149756	1	<b>PULL OUT TRAYS:</b> FABRICATE (2) PULL OUT TRAYS WITH 1" LIPS AND INSTALL IN THE LOWER REAR MAIN WALL CABINET. INSTALL GAS SHOCKS TO HOLD TRAYS IN THE OPEN AND CLOSED POSITIONS. INSTALL (1) FIXED PULL OUT TRAY ON THE BOTTOM OF THE CABINET. INSTALL (1) ADJUSTABLE PULL OUT TRAY IN THE CENTER OF THE CABINET. PULL OUT TRAY IN THE LOWER REAR MAIN WALL CABINET. NO DOORS INSTALLED ON THE LOWER REAR MAIN CABINET. DIMENSIONS ARE 36.5W X 22.75H X 16D I.D.
2900-0410	1	<b>LIFT UP CABINET FRAMES, UPPER INHALATION CABINET</b> Install a flip-up restocking cabinet frame on cabinet noted above. Includes gas shocks and vertical latches. <b>The Design is to be compliant with Change Notice 10.</b>
2000-2058	1	<b>UPPER INHALATION CABINET 52.75" W x 18.75" H x 18" D (ID)</b> Upper inhalation cabinet dimensions are to be as noted above. Note that dimensions are I.D.
2000-1368	1	<b>POLYCARBONATE SLIDING, UPPER INHALATION, CHANGE 10</b> Cabinet over inhalation area is to have sliding polycarbonate doors. Doors to include CN-10 compliant catch.

Spec Writer: **Levi C**

Spec Designer:

**CITY OF HOLLYWOOD**

Option	QTY	Description
2900-1094	1	<b>INTERIOR SHELVING, UPPER INHALATION CABINET</b> Install painted adjustable shelving in upper inhalation cabinet.
SR00149842	1	<b>SHARPS CONTAINER MAIN WALL</b>  Install a sharps cabinet to the rear telemetry wall after the CPR seat. Dealer supplied container will be enclosed with hinged lid with locking southco latch. See drawings for dimensions.
<b>CURBSIDE CABINERY</b>		
SR00149801	1	<b>CRASH BARRIER CONFIGURATION</b>  REQUIRES 75" SQUAD BENCH LENGTH. MODIFY THE BENCH PAN DUE TO THE CRASH BARRIER CONFIGURATION AND THE HORIZONTAL BOTTLE STORAGE. CURBSIDE WHEEL HOUSE WILL EXTEND TO THE CRASH BARRIER AND THE REAR COMPARTMENT
SR00149803	1	<b>DRUG BOX</b>  FABRICATE A DRUG BOX ON WALL AT HEAD OF BENCH PER DRAWING. WILL INCLUDE A LEFT HINGED DOOR, SOUTHCO STAINLESS STEEL PULL RING LATCH. MEDECO LOCK INSTALLED BELOW THE PULL RING LATCH.
SR00149811	1	<b>SQUAD BENCH STORAGE:</b> SQUAD BENCH IS TO BE RAISED 2" TO ALLOW FOR THE INSTALLATION OF (2) ZICO QRM-V UNIVERSAL BOTTLE BRACKETS. INSTALLED SIDE BY SIDE AND SET UP FOR "M" SIZE CYLINDERS WITH THE BOTTLE NECKS FACING THE FORWARD END OF THE BENCH. STORAGE AREA IS TO BE VENTED TO THE OUTSIDE. REAR CUSHION OVER CURBSIDE REAR COMPT. IS TO BE FIXED. FORWARD CUSHION TO HINGE UP FOR BOTTLE ACCESS.
2000-0359	1	<b>SQUAD BENCH WITH NO CUPS OR WELLS</b> Provide storage under the squad bench lid/cushion(s). The area shall run where possible under the bench. The storage pan is to be fabricated from aluminum and painted to match the interior.
8000-0056	1	<b>BENCH END RESTRAINT FOR USE WITH HOPS, DELETE</b>
2000-0377	1	<b>CARGO NET-HEAD OF BENCH</b> Install a cargo net at the head of the bench. Net to be removeable for cleaning purposes.
2000-0744	1	<b>DOUBLE CUSHION SQUAD BENCH</b> The squad bench cushion is to be two piece.
2000-0380	1	<b>BENCH HOLD OPENS: GAS</b> Install gas spring hold opens on squad bench lid.
2000-0585	1	<b>BENCH HOLD-DOWN: PADDLE LATCHES (SINGLE)</b>

Spec Writer: **Levi C**

Spec Designer:

**CITY OF HOLLYWOOD**

Option	QTY	Description
		Install a recessed paddle latch into the squad bench riser to retain the squad bench lid in the closed position.
<b>2000-0382</b>	<b>1</b>	<b>BENCH CUSHION EDGE TRIM:</b> Trim bench cushion edge with protective aluminum trim, to protect horizontal edge of squad bench cushion from tears.
<b>2000-0383</b>	<b>1</b>	<b>BENCH BACK CUSHION: FULL SIZE</b> Install full size bench backrest cushion.
<b>SR00149749</b>	<b>1</b>	INSTALL A CABINET IN THE HEAD END OF THE BENCH FOR WASTE CONTAINER. WILL BE RECESSED INTO THE COUNTER AT HEAD OF THE BENCH AS CLOSE TO THE BENCH AS POSSIBLE. CUSTOMER WILL SUPPLY WASTE CONTAINER. INCLUDE A LAMINATED HINGE UP LID W/WASTE OPENINGS.
<b>SR00149806</b>	<b>1</b>	<b>FABRICATE AND INSTALL A BENCH CEILING CABINET ABOVE THE SQUAD BENCH WITH TWO (2) LIFT UP PLEXIGLAS DOORS WITH SOUTHCO LATCHES. EACH DOOR IS TO INCLUDE A GAS HOLD OPEN. THE FORWARD SECTION IS TO INCLUDE SPACE FOR FOUR (3) GLOVE BOXES WITH OVAL ACCESS HOLE AND SOUTHCO LATCH. SEE DRAWINGS FOR DIMENSIONS.</b>
<b>2900-1130</b>	<b>3</b>	<b>SOUTHCO LATCH OVERHEAD BENCH CABINET</b> Install stainless flush mount Southco pull latches on the bench ceiling cabinet.
<b>2900-1137</b>	<b>8</b>	<b>COMPRESSION HINGES, OVERHEAD BENCH CABINET</b> The bench ceiling cabinet door(s) is/are to use compression style hinges.
<b>SR00149821</b>	<b>1</b>	SHARPS/WASTE, FOOT OF BENCH  Install a dealer supplied sharps container, and a Horton supplied waste container at the foot of the bench per drawing. Include hinged lid for access to the containers.
<b>FRONT WALL CABINETRY</b>		
<b>2000-1403</b>	<b>1</b>	<b>CAB TO MODULE WALKTHROUGH DOOR, 180 DEGREE</b> Install a 180 degree hinged pocketed front cabin closeout door on the front bulkhead.
<b>COT MOUNT</b>		
<b>2000-0595</b>	<b>1</b>	<b>STRYKER POWER LOAD, OFFSET Cot Type: None</b> Supply and install a Stryker Power load system. Locate 5" off center. This option does not include a cot. Note: this option complies with GSA change notice 8.
<b>VISUAL WARNING</b>		
<b>SR00149764</b>	<b>1</b>	REAR LIGHT BAR: MODEL: CODE 3 FM9000 75" BAR WITH REF8 LIGHTS [RED][BLUE][YELLOW][RED][BLUE][RED][YELLOW][BLUE][RED] HORTON TO INSTALL LED ICC/BRAKE LIGHTS ON CENTER OF LIGHT BAR TO MATCH PREVIOUS VEHICLES - 17616-17618
<b>3000-1231</b>	<b>1</b>	<b>FRONT LIGHTBAR</b>

Spec Writer: **Levi C**

Spec Designer:

**CITY OF HOLLYWOOD**

Option	QTY	Description
		Install a front lightbar as noted.
<b>SR00149789</b>	<b>1</b>	<b>WHELEN 60" FREEDOM LIGHT BAR - FRONT:</b>  CONFIGURE: (Red) (Red) (Red) (White) (Red) (Red) (White) (White) (Red) (Red) (White) (Red) Red) (Red)  LENS: CLEAR
<b>3000-0037</b>	<b>1</b>	<b>LIGHT BAR MOUNT: CAB ROOF</b> Install the selected front lightbar on the cab roof.
<b>3000-1808</b>	<b>1</b>	<b>WIG WAG HEADLIGHTS, FREIGHTLINER</b> Install wig wag headlight flasher. Provide a dedicated switch in the front control panel. Deactivate with high beams and in secondary mode.
<b>3300-0052</b>	<b>3</b>	<b>M6, AMBER/AMBER LENS 2 wheel well corners - 1 centered above rear entry doors</b> Install Whelen M6 series LED lights as noted. Lights to be amber with amber lenses. Lights to include chrome flanges and flash pattern programmability from the front control panel.
<b>3000-0066</b>	<b>4</b>	<b>M9, AMBER/AMBER LENS 2 rear face upper window level / 1 ss - rear upper outboard corners/ 1 curbside rear upper outboard corners</b> Install Whelen M9 series LED lights as noted. Lights to be amber with amber lenses. Lights to include chrome flanges and flash pattern programmability from the front control panel.
<b>3400-0068</b>	<b>10</b>	<b>M9, RED/RED LENS 2 front face/2 rear face upper corners/2 rear face-lower window level 2 rear face -lower doors/1 streetside forward upper outboard corner / 1 curbside - forward upper outboard corner</b> Install Whelen M9 series LED lights as noted. Lights to be red with red lenses. Lights to include chrome flanges and flash pattern programmability from the front control panel.
<b>3200-5015</b>	<b>6</b>	<b>M7 R/W SPLIT/CLEAR LENS 4 chassis grille - red outboard / 2 intersections - white forward</b> Install Whelen M7 series LED lights as noted. Lights to be red/white split with clear lenses. Lights to include chrome flanges and flash pattern programmability from the front control panel.
<b>3000-0144</b>	<b>1</b>	<b>FLASH PATTERN, 80 FPM A/B</b> Program the emergency lighting flash pattern to 80 FPM A/B.
<b>AUDIBLE WARNING</b>		
<b>SR00150478</b>	<b>1</b>	<b>AIR HORNS</b>  GROVER DUAL #1510 TRUMPETS. TRUMPET LOCATIONS: EACH SIDE OF CAB HOOD, ACTIVATION TYPE: BUTTON ON PASSENGER SIDE CONSOLE (Note: Wire and leave loose with console). FOOT SWITCH ON DRIVERS SIDE. NOTE: LOCATE STORAGE TANK BENEATH MODULE ON FRAME RAIL. UPGRADE COMPRESSOR TO THE BUELL #16122 FAST RECOVERY MODEL AND INSTALL (1) LARGER CAPACITY VELVAC AIR TANK ILOS.
<b>SR00149814</b>	<b>1</b>	<b>CHROME BUTTON: Locate air horn button on the passenger's side of console plate above the whelen siren switch. See drawing.</b>

Spec Writer: **Levi C**

Spec Designer:

**CITY OF HOLLYWOOD**

Option	QTY	Description
<b>3000-0169</b>	<b>1</b>	<b>FOOT SWITCH, AIR HORN, DRIVER'S SIDE</b> Install a driver's side foot switch for air horn activation.
<b>SR00149828</b>	<b>1</b>	COLE HERSEE  COLE HERSEE #9231 SWITCH ON PASSENGER SIDE CONSOLE
<b>SR00160859</b>	<b>1</b>	FOOT SWITCH, SIREN, DRIVER'S SIDE  Install a driver's side foot switch for siren activation.
<b>3000-0170</b>	<b>1</b>	<b>SIREN, WHELEN WS295SLSC1 T1 - Wail T2 - Yelp T3 - Piercer</b> Install a Whelen WS295SLSC1 siren in the front console.
<b>SR00149751</b>	<b>1</b>	SIREN ACTIVATION: STEERING WHEEL HORN RING, FOOT SWITCH ON THE DRIVER SIDE FLOOR.
<b>3000-1544</b>	<b>1</b>	<b>SPEAKERS, CAST PRODUCTS, FREIGHTLINER</b> Install Cast Products siren speakers, applicable to Freightliner chassis, in the front bumper.
<b>NON-EMERGENCY LIGHTING</b>		
<b>SR00149770</b>	<b>1</b>	GO-LIGHT - STRYKER MODEL 20074GT  INSTALL ON THE CHASSIS ROOF JUST BEHIND THE LIGHTBAR. INSTALL ON A FABRICATED HAT SECTION SO IT WILL BE SEEN OVER THE LIGHTBAR. INTERIOR CONTROLS ARE TO BE INSTALLED DURING CUSTOMER INSPECTION.
<b>3000-0208</b>	<b>1</b>	<b>KKK SIDE BODY MARKER LIGHTS, M6 SERIES LED (PAIR)</b> Install red Whelen M6 series LED turn/marker lights on each rear side of the module body. Lights provide module body night time side lighting visibility and turning signal indication. Lights do not flash with warning lights unless otherwise specified. Includes chrome flanges.
<b>3000-0217</b>	<b>1</b>	<b>LED EXTERIOR COMPARTMENT LIGHTING</b> Install full height LED strip lighting in all exterior compartments with the exception of any wheelwell compartments. Install vertical strips inside both sides of each compartment. The lights are to be directed toward the back of each compartment.
<b>3000-0711</b>	<b>1</b>	<b>WELDON LED MARKER LIGHTS</b> Weldon LED ICC marker lights are to be installed. Do not install in cases where a selected lightbar already includes ICC marker lights.
<b>SR00149817</b>	<b>1</b>	ADDITIONAL ICC MARKER LIGHTS: WHELEN OS MARKER LIGHTS. FORWARD LIGHTS ARE TO BE LOCATED IN THE UPPER FORWARD CORNER OF THE BODY ABOVE THE DOORS.  (1) AMBER SS FORWARD OF BODY, UNDER DRIP RAIL (1) RED STREETSIDE REAR OF BODY, UNDER DRIP RAIL (1) AMBER CURBSIDE FORWARD OF BODY, UNDER DRIP RAIL

Spec Writer: **Levi C**

Spec Designer:

**CITY OF HOLLYWOOD**

Option	QTY	Description
		(1) RED CURBSIDE REAR OF BODY, UNDER DRIP RAIL PROGRAM THE STREETSIDE FORWARD AMBER MARKER LIGHT TO STAY ON IF THE BATTERY SWITCH IS ON.
<b>3000-1625</b>	<b>1</b>	<b>WHELEN PFP2 DUAL PANEL STREETSIDE CENTER</b> Install a Whelen PFP2 dual panel super LED floodlight on the streetside of the body in the center position. Install using a PBA203 semi-recess housing.
<b>3000-1624</b>	<b>1</b>	<b>WHELEN PFP2 DUAL PANEL CURBSIDE CENTER</b> Install a Whelen PFP2 dual panel super LED floodlight on the curbside of the body in the center position. Install using a PBA203 semi-recess housing.
<b>SR00149850</b>	<b>1</b>	<b>WHELEN PFP1 SINGLE PANEL PIONEER PLUS SUPER LED FLOODLIGHT</b> LOCATE: (2) REAR OF THE BODY ABOVE THE REAR ENTRY DOORS AS LOAD LIGHTS INSTALL A SWITCH IN THE FRONT CONTROL PANEL AND WIRE TO OPERATE AS THE LOAD LIGHTS.
<b>SR00149744</b>	<b>1</b>	RED WARNING LIGHTS, SIDE ACCESS DOOR  INSTALL (1) TECNIQ RED L.E.D. LIGHT STRIP ON THE UPPER MODULE SIDE ACCESS DOOR INNER PANELS.  INSTALL ONE (1) TECNIQ RED L.E.D. LIGHT STRIP ON THE LOWER MODULE SIDE ACCESS DOOR INNER PANELS.  INSTALLATION WILL BE NEAR FLUSH WITH THE INNER DOOR PANELS. THE LIGHT STRIPS ARE TO FLASH WHEN THE ACCESS DOORS ARE OPEN, AND THE EMERGENCY LIGHTING IS ACTIVATED.
<b>SR00149796</b>	<b>1</b>	RED WARNING, TOP, ACCESS DOORS  INSTALL TECNIQ RED L.E.D. LIGHT STRIPS ON THE UPPER REAR MODULE ACCESS DOOR INNER PANELS, (2) PER DOOR (4 TOTAL). INSTALLATION WILL BE NEAR FLUSH WITH THE INNER DOOR PANELS. THE LIGHT STRIPS ARE TO FLASH WHEN THE ACCESS DOORS ARE OPEN, AND THE EMERGENCY LIGHTING IS ACTIVATED.
<b>3000-0660</b>	<b>1</b>	<b>RED WARNING LIGHT, TOP, STREETSIDE FRONT</b> Install a Tecniq red L.E.D. light strip on the upper streetside forward compartment door inner panel. Installation will be near flush with the inner door panel. The light strip is to flash when the compartment door is open, and the emergency lighting is activated.
<b>3000-0661</b>	<b>1</b>	<b>RED WARNING LIGHT, TOP, STREETSIDE INTERMEDIATE</b> Install a Tecniq red L.E.D. light strip on the upper streetside intermediate compartment door inner panel. Installation will be near flush with the inner door panel. The light strip is to flash when the compartment door is open, and the emergency lighting is activated.
<b>SR00149845</b>	<b>1</b>	RED WARNING LIGHT, TOP, SS WHEELWELL

Spec Writer: **Levi C**

Spec Designer:

**CITY OF HOLLYWOOD**



Option	QTY	Description
		Install a Tecniq red L.E.D. light strip on the upper streetside wheelwell compartment door inner panel. Installation will be near flush with the inner door panel. The light strip is to flash when the compartment door is open, and the emergency lighting is activated.
<b>3000-0662</b>	<b>1</b>	<b>RED WARNING LIGHT, TOP, STREETSIDE REAR</b> Install a Tecniq red L.E.D. light strip on the upper streetside rear compartment door inner panel. Installation will be near flush with the inner door panel. The light strip is to flash when the compartment door is open, and the emergency lighting is activated.
<b>SR00149782</b>	<b>1</b>	<b>RED WARNING LIGHT, TOP, CRASH BARRIER</b>  Install a Tecniq red L.E.D. light strip on the upper crash barrier compartment door inner panel. Installation will be near flush with the inner door panel. The light strip is to flash when the compartment door is open, and the emergency lighting is activated.
<b>3000-0659</b>	<b>1</b>	<b>RED WARNING LIGHT, TOP, CURBSIDE REAR</b> Install a Tecniq red L.E.D. light strip on the upper curbside rear compartment door inner panel. Installation will be near flush with the inner door panel. The light strip is to flash when the compartment door is open, and the emergency lighting is activated.
<b>SR00160852</b>	<b>1</b>	<b>RED WARNING LIGHT NOTE</b>  Install on rear-facing doors only.
<b>3000-1439</b>	<b>1</b>	<b>TAIL LIGHTS, M9 SERIES, HORIZONTAL MOUNTED</b> Install Whelen M9 series LED stop/tail, turn, and reverse lights. Install the stop/tail and reverse lights in the rear riser/kick plate with brake/tail outboard. Install the turn signals above in the rear body panels. Lights to include chrome flanges.
<b>ELECTRICAL</b>		
<b>SR00149851</b>	<b>1</b>	<b>5ft Coiled Service Loops</b>  Install (3) 5ft coiled service loops in the locations below:  (1) Streetside Rear Compartment (2) Curbside Rear Compartment  Use 14 gauge wire.
<b>3000-0018</b>	<b>1</b>	<b>ELECTRIC DOOR LOCKS COMPARTMENT EXTERIOR</b> Install power activated door locks on all exterior compartment doors. Locks to be activated by a switch at each patient area access door. Locks may be overridden by a door key.
<b>3000-0019</b>	<b>1</b>	<b>ELECTRIC DOOR LOCKS ACCESS DOORS INTERIOR</b> Install power activated door locks on all patient area access doors. Locks to be activated by a switch at each patient area door. Locks may be overridden by a manual slide lever or by the door key.
<b>3000-0022</b>	<b>1</b>	<b>ELECTRIC DOOR LOCKS WIRED TO OEM SWITCHES</b>

Spec Writer: **Levi C**

Spec Designer:

**CITY OF HOLLYWOOD**

Option	QTY	Description
		The specified power door locks are to be wired to the chassis OEM door lock switches.
<b>SR00149793</b>	<b>1</b>	<p><b>ELECTRIC DOOR SWITCH - CONCEALED:</b>  (1) UNDER CURBSIDE FORWARD CORNER POST.  INSTALL THE ADDITIONAL CONCEALED SWITCH UNDER A SHORELINE COVER REARWARD OF THE SHORELINE OUTLET ON THE STREETSIDE OF THE BODY. THIS SWITCH IS TO BE A LOCK ONLY SWITCH.</p> <p>INSTALL THE CONCEALED SWITCH AND COVER ON A SINGLE MIRRORED STAINLESS STEEL PLATE. MIRRORED STAINLESS STEEL PLATE IS TO BE LARGE ENOUGH FOR THE CONCEALED SWITCH, SHORELINE OUTLET, AND THE SHORLINE INDICATOR.</p>
<b>3000-0282</b>	<b>1</b>	<p><b>ELECTRICAL SYSTEM</b>  Install the Intelliplex i4G electrical system. System is to include a USB port installed under the dash for ease of programming.</p>
<b>3000-0285</b>	<b>1</b>	<p><b>MODULE DISCONNECT TIMER</b>  The module disconnect circuit shall time out if left in the 'On' position with the engine off and battery switch in the 'On' position.</p>
<b>3000-0293</b>	<b>1</b>	<p><b>BATTERY SWITCH: STD. OPERATION</b>  Install standard battery switch and wire to Horton-installed components only. Do not tie into chassis circuits.</p>
<b>3000-1511</b>	<b>1</b>	<p><b>LIFESINE INVERTER/CHARGER, INTERFACE SWITCH</b>  Install a Vanner #LSC12-1100 LifeSine Inverter/charger in the streetside intermediate compartment as noted. Unit is to function through a switch located in the control panel. Status panels are selected separately.</p>
<b>3000-2151</b>	<b>1</b>	<p><b>VANNER CHARGER/STATUS PANEL</b>  Install a Vanner charger/status panel in standard locations.</p>
<b>3000-0310</b>	<b>3</b>	<p><b>110V INTERIOR OUTLET 2 forward In Inhalation Area And 1 bench wall over the crash barrier compt</b>  Install a 110V outlet(s) as noted.</p>
<b>3000-0549</b>	<b>7</b>	<p><b>INTERIOR 12VDC OUTLETS: CL TYPE/USB (2) forward inhalation area/(1) bench wall over crash barrier compt./(1) in crash barrier compartment/(2) On console per drawing (1) lower linen closet - far upper left corner for fridge, must be recessed</b>  Install a 12VDC cigarette style/USB outlet(s) as noted. Wire battery hot.</p>
<b>SR00149742</b>	<b>1</b>	<p><b>Horton to supply and install a kussmaul usb port # 091-219-4 on passenger side of console.</b></p>
<b>3000-1465</b>	<b>1</b>	<p><b>SHORELINE 1, 20A SUPER AUTO EJECT, YELLOW</b>  Mount a Kussmaul Super Auto Eject 20 amp shoreline inlet in the standard location. Cover is to be yellow.</p>
<b>SR00149818</b>	<b>1</b>	<p><b>SHORELINE KUSSMAUL - AUTO EJECT: THE SHORELINE OUTLET IS TO BE INSTALLED ON A SINGLE MIRRORED STAINLESS STEEL PLATE ALONG WITH THE CONCEALED SWITCH, COVER AND THE SHORELINE INDICATOR.</b></p> <p>SHORELINE COVER IS TO BE YELLOW</p>

Spec Writer: **Levi C**

Spec Designer:

**CITY OF HOLLYWOOD**

Option	QTY	Description
<b>3000-1502</b>	<b>1</b>	<b>PD BOX LOCATION, FRONT CONSOLE</b> Install the power distribution box inside the front console.
<b>3000-0324</b>	<b>1</b>	<b>SHORELINE INDICATOR 1:</b> Install an indicator pilot light to show power to A.C. circuits and presence of activated primary shoreline.
<b>3000-0327</b>	<b>1</b>	<b>EXTRA 12VDC CIRCUIT BREAKER: INTERMEDIATE COMPT</b> An extra circuit breaker shall be installed in the streetside intermediate compartment.
<b>3000-0332</b>	<b>1</b>	<b>REPORT LIGHT, LED</b> Install a 12" LED report light on the action wall to light the counter area.
<b>3000-0344</b>	<b>2</b>	<b>STEP WELL LIGHT VISTA LED</b> Install a 10.5" LED Vista light strip in the standard location on the bench side of the step well. Light to activate with door open.
<b>3000-0581</b>	<b>1</b>	<b>ROM DUROLUMEN LED ABOVE CHEST IN CEILING</b> A ROM Durolumen light fixture shall be provided and installed as noted above. Fixture is to be operable from the rear switch panel as well as through other means as noted within this document.
<b>3000-0583</b>	<b>1</b>	<b>ROM DUROLUMEN LED ABOVE WAIST IN CEILING</b> A ROM Durolumen light fixture shall be provided and installed as noted above. Fixture is to be operable from the rear switch panel as well as through other means as noted within this document.
<b>SR00149841</b>	<b>1</b>	<b>ROM DUROLEM LIGHT NOTE: INCLUDE SWITCH IN THE REAR CONTROL PANEL.</b>
<b>3000-0359</b>	<b>10</b>	<b>PATIENT CEILING DOME LIGHTS WHELEN LED</b> Install Whelen 80COEHCR LED dome lights in the patient area ceiling. The lights will have a high/low feature with the switch in the rear control panel.
<b>3000-0525</b>	<b>1</b>	<b>3 SWITCH PANEL REAR DOOR PANEL</b> Install an i4G 3-switch control panel on the right rear entry door panel.
<b>3000-2103</b>	<b>1</b>	<b>TIMER, DOME LIGHTS, REAR DOOR PANEL</b> Install an electronic momentary touch timer switch in the specified I4g switch panel on the right rear door panel. The switch will enable time limited operation of the specified dome lights with the battery switch in the 'off' position. Set timer to 15 minutes.
<b>3000-5042</b>	<b>1</b>	<b>DUMP OVERRIDE, i4G, REAR DOOR PANEL</b> Install the dump override switch in the panel selected for the right rear entry door inner panel.
<b>SR00149819</b>	<b>1</b>	PRE-WIRE - STREAMLIGHT INSTALL  (1) BEHIND DRIVERS SEAT IN CAB (1) BEHIND PASS. SEAT IN CAB (1) RIGHT FRONT WALL AREA ( HAND LIGHT POWER GROUND WIRING ONLY INSTALL) INCLUDE A 36" LONG SERVICE LOOP ON EACH AND WIRE BOTH BATTERY HOT
<b>3000-0367</b>	<b>1</b>	<b>GOOSE NECK PANEL LIGHT</b> Install a flexible goose neck panel light on the passenger side of the front console.

Spec Writer: **Levi C**

Spec Designer:

**CITY OF HOLLYWOOD**

Option	QTY	Description
3000-0007	1	<b>BACKUP ALARM RESET, MOMENTARY</b> Install a back-up alarm and provide a momentary backup alarm reset button on the front console.
3000-0031	1	<b>CAMERA LOCATION: OVER REAR DOORS, EXTERIOR</b> The integrated camera system noted is to include a camera installed over the rear doors on the vehicle exterior for use in reverse.
3000-0032	1	<b>CAMERA LOCATION: OVER REAR DOORS, INTERIOR</b> The integrated camera system noted is to include a camera installed over the rear doors on the vehicle interior for use as a patient compartment monitor.
<b>PROGRAMMING</b>		
SR00150487	1	<b>PROGRAMMING - Compartment and door lighting to activate with headlights.</b>
6000-0001	1	<b>LIGHT PROGRAMMING: SIDE REAR SCENE</b> The side rear scene lights shall be wired to transmission reverse, plus standard mode of operation.
6000-0002	1	<b>LIGHT PROGRAMMING: RIGHT SIDE SCENE</b> The right side scene lights shall come "on" when the side patient door is opened.
6000-0003	1	<b>LIGHT PROGRAMMING: LOAD LIGHT</b> Program the rear load lights to activate with transmission reverse plus the standard mode of operation.
6000-0019	1	<b>REAR LIGHT DIMMER SWITCH</b> Provide a switch in the front control panel to dim all rear-facing lights to 50% illumination.
6000-0005	1	<b>LIGHT PROGRAMMING: MODULAR DISCONNECT TIMER</b> The module disconnect shall be wired to automatically shut-down when inadvertently left in the on position, with the engine turned OFF and the battery switch in the ON position.
6000-0006	1	<b>PROGRAMMING: AUDIBLE LOW VOLTAGE ALARM</b> Program an audible alarm to activate if the voltage drops below 11.8 volts for 120 seconds.
SR00149799	1	LIGHT PROGRAM PARK BRAKE: CONFIGURE: Program a warning to display on the front console readout advising to set the Parking Brake when the module disconnect switch is "ON" and the transmission is placed in "PARK" or "NEUTRAL". It will also advise to Disengage the Parking Brake should the vehicle be placed into gear.  NOTE - WIRE ALARM TO ACTIVATE WITH THE RED FLASHER CIRCUIT.  SUPPLY A RED WHELEN OS MARKER LIGHT AND ADD PARKING BRAKE LIGHT NEAR THE PARK BRAKE
SR00149820	1	LIGHT PROGRAM - BRAKE LIGHT: FLASHERS ARE TO OVERRIDE THE BRAKE LIGHT FEATURE. - FEATURE IS TO ACTIVATE REGARDLESS OF THE MODULE DISCONNECT STATUS
SR00149759	1	MINIMUM WARNING SWITCH IN THE I4G: WIRE ONLY CORNER RED MODULE LIGHTS AND REAR AMBER LIGHTS.

Spec Writer: **Levi C**

Spec Designer:

**CITY OF HOLLYWOOD**

Option	QTY	Description
<b>SR00149823</b>	<b>1</b>	FLASHING SEQUENCE: PROGRAM ALL THE "M" SERIES LIGHTS FOR FAST RANDOM FLASH AT THE LIGHthead. DO NOT FLASH THRU THE I4G. ALL LIGHTS ARE TO REMAIN ON IN SECONDARY MODE EXCEPT THE WHITE LIGHTS.
<b>SR00149840</b>	<b>1</b>	LIGHT PROGRAMMING TIME OUT - 5 MIN. CONFIGURE: DO NOT TIME OUT IF THE SHORELINE IS CONNECTED.
<b>3000-1269</b>	<b>1</b>	<b>MODULE DISCONNECT, DEFAULT TO "ON"</b> Program the Module Disconnect to 'On' with battery activation.
<b>HVAC</b>		
<b>SR00149787</b>	<b>1</b>	MAXCOOL II DUAL A/C UNIT: HEAD OF BENCH ANGLED TOWARDS REAR. INCLUDE REMOVABLE FILTERS. UNIT WILL BE CONTROLLED THRU THE I4G AND INCLUDE MULTIPLE FAN SPEEDS TO DUPLICATE THE STANDARD A/C UNIT. VEHICLE WILL INCLUDE (2) PROAIR 938 UNITS FOR COOLING ONLY. THE CLOSEOUT FOR THE UNIT LOCATED AT THE UPPER FORWARD END OF THE CURBSIDE WALL HAS BEEN MINIMIZED PER PREVIOUS ORDERS.
<b>SR00149805</b>	<b>1</b>	HEAT/A.C - TOP MT. CONDENSER: 3 FAN CONDENSER ILO 2-FAN DUE TO THE PROAIR 938 UNIT ABOVE THE CRASH BARRIER. PAINT CONDENSER GRAY. INSTALL REMOVABLE FILTERS AT THE INTAKE POINT. INSTALL ON MAXCOOL AND STANDARD AC UNIT. A/C ONLY - NO HEAT
<b>SR00149856</b>	<b>1</b>	12V HVAC, ATTENDANT'S SEAT  Install a ProAir Pre-charged 12V AC system with brushless motor below the attendant seat.
<b>3000-0424</b>	<b>1</b>	<b>3-PLY PANEL INTAKE FILTER</b> Install a 3-Ply Panel air intake filter ILOS.
<b>2000-0435</b>	<b>1</b>	<b>VENT CAST PAINTED NFPA STYLE</b> Install an NFPA style venting system to include a 400cfm exhaust fan along with a static vent. Install 9.5" square cast covers on both vents per drawings. Covers to be painted body color.
<b>RADIO</b>		
<b>3000-0432</b>	<b>1</b>	<b>ANTENNA COAX 1 Start: Behind Driver Seat, End: Front Center of Mod Roof</b> An RG 58U coax shall be installed terminating as noted above.
<b>3000-0608</b>	<b>1</b>	<b>ANTENNA COAX 2 Start: Behind Driver Seat, End: Center of Mod Roof</b> An RG 58U coax shall be installed terminating as noted above.

Spec Writer: **Levi C**

Spec Designer:

**CITY OF HOLLYWOOD**

Option	QTY	Description
SR00149741	1	ANTENNA COAX #2 NOTE  COAX #2 IS TO HAVE A 48" SERVICE LOOP.
3000-1174	1	<b>PULL WIRE 1 Start: Behind Driver Seat, End: Inhalation Wall</b> Install a radio cable pull wire terminating as noted above. Wire is not to be wire tied or otherwise prevented from moving freely.
3000-0438	1	<b>RADIO HEAD PRE-CUT: FRONT customer has not supplied</b> Provide a radio head pre-cut in the front console faceplate. Radio head model is noted.
1000-0414	1	<b>CONSOLE, LINE-X, W/MAP STORAGE, FREIGHTLINER</b> Fabricate and install an aluminum cab console and spray with black Line-X material. Console is to include three (3) map/book slots at the rear of the console.
SR00149825	1	FRONT CONSOLE EXTENSION: TO BE DARK GRAY SCORPION COATED CONSOLE SECTION TO HAVE (4) STORAGE SECTIONS ILO (3) SECTIONS AND INCLUDE ADJUSTABLE DIVIDERS  FRONT CONSOLE, REINFORCE THE PASSENGER SIDE OF THE CAB CONSOLE FOR FUTURE INSTALL OF THE MDT MOUNT  USE DZUS FASTENERS ON THE CONSOLE ILO SCREWS
3000-5157	1	<b>POWER TERMINAL, DUAL, INSIDE CONSOLE</b> Install three (3) 10 gauge 30 amp cables to positive and ground studs for radio power. Wire one constant hot, one battery switched, and the third as a ground.
3000-5160	1	<b>POWER TERMINAL, DUAL, INHALATION PANEL</b> Install three (3) 10 gauge 30 amp cables to positive and ground studs for radio power. Wire one constant hot, one battery switched, and the third as a ground.
3000-5025	1	<b>POWER TERMINAL, SWITCHED, BEHIND DRIVER</b> Install two (2) 10 gauge 30 amp cables to positive and ground studs for radio power. Wire one battery switched and the other as a ground. Locate behind the driver's seat.
<b>OXYGEN</b>		
4000-0008	1	<b>DUAL O2 BOTTLE SYSTEM, 1-REGULATOR W/CHECK VALVES</b> Plumbing will be provided for (2) O2 bottles. One O2 regulator will be provided with check valves in the lines coming from each tank.
4000-0010	1	<b>O2 TRANSFILL SYSTEM W/6' STAINLESS HOSE</b> Plumbing shall be provided inside the O2 compartment for remote filling of the O2 bottle. Feature is to include a 6' stainless steel hose.
SR00149753	1	DUAL O2 BOTTLE SYSTEM NOTES:  TWO (2) O2 BOTTLE BRACKETS ARE TO BE INSTALLED THE SQUAD BENCH PAN TOWARDS THE REAR AS FAR AS POSSIBLE. IT IS TO BE SET UP FOR A TRANSFILL SYSTEM WITH HOSE VALVE. INSTALL A 6' STAINLESS STEEL BRAIDED FILL HOSE, FIXED MOUNTED IN THE LEFT (REAR) WALL OF THE CRASH BARRIER COMPT. INSTALL A 90 DEGREE FITTING THAT FACES

Spec Writer: **Levi C**

Spec Designer:

**CITY OF HOLLYWOOD**

Option	QTY	Description
		OUTWARDS FOR EASY ACCESS. REFERENCE 19423-424
4000-0022	1	<b>O2 OUTLET, OHIO MEDICAL (1) Inhalation Panel</b> Install O2 outlets per instructions above. Outlets to be Ohio Medical style.
4000-0024	1	<b>FLOWMETER: DIAL TYPE</b> Supply dial type flowmeter.
4000-0025	1	<b>OXYGEN WRENCH</b> Install oxygen wrench in oxygen compartment. Mount securely to wall. Mount with length of chain or cable to allow for use without being removed from the compartment.
3000-0642	1	<b>VACUUM OUTLET, OHIO MEDICAL 1 In Inhalation Area</b> Install a single Ohio style vacuum outlet. Locate per drawings.
4000-0179	1	<b>ASPIRATOR, SSCOR, INHALATION AREA</b> Install an SSCOR aspirator. The system shall include a wall mounted regulator and a canister holder. Plumb to the selected pump.
4000-0089	1	<b>VACUUM PUMP CAPL #D34 SE (P282)</b> Install a CAPL #D34 SE (P282) 12vdc electric suction pump.
<b>CERTIFICATIONS</b>		
7000-0001	1	<b>KKK-A-1822F CERTIFICATION LABEL</b> The vehicle shall have weight/payload, electrical load and KKK-A-1822F certification stickers installed in the O2 compartment.
7000-0003	1	<b>CHANGE NOTICE 10 CERTIFICATION</b> The vehicle shall be certified to change notice 10 standards.

Spec Writer: **Levi C**

Spec Designer:

**CITY OF HOLLYWOOD**